

# Work Order ID 76516

**\*76516\***

Page 1

November-16-11 12:02:33 PM

Item ID: D2661-1

Accept

**\*N900040100\***

Setup Start **\*NS1\***

Revision ID:

Stop **\*NS2\***

Item Name: Saddle, LH Fwd Aft Out 206

Start Date: 11/16/11 Start Qty: 4.00

**\*4\***

Cust Item ID:

Required Date: 11/17/11 Req'd Qty: 4.00

**\*4\***

Customer: CU-DAR001

Reference: RMA RA111291 - RETURN

Approvals: Process Plan: *W*

Date:

Tooling:

Date:

Run Start **\*NR1\***

QC:

Date:

SPC (Y/N):

Date:

Stop **\*NR2\***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr

Revision Nbr

D2661

Rev D

100

0.00

**\*100\***

QC

Memo

0.00

Quality Control

INSPECT RA111291

*8 x 1/4/16*

*B 73839*

*x4*

110

0.00

**\*110\***

Packaging

Memo

0.00

Packaging

RETURN TO STOCK USING NEW B/N

*11/16/17 (4)*

120

QC21- Final Inspection - Work Order Release

0.00

**\*120\***

QC

Memo

0.00

Quality Control

*11/16/17 (4)*



# Picklist Print

November-16-11 12:02:33 PM

Page 1

Work Order ID: 76516

Parent Item: D2661-1

Start Date: 11/16/11

Required Date: 11/17/11

Parent Item Name: Saddle, LH Fwd Aft Out 206

Start Qty: 4.00

Required Qty: 4.00

Comments: IPP: C00.11.01Removed P/O for Powder Coat - in house processEC  
IPP Rev:D As per Rev D 07-03-19 JLM

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D2661-1		Manufactured	No				Each	1.0000		4			
Saddle, LH Fwd Aft Out 206													

Location

Loc Qty

Loc Code

ST435

1

73841

1

73839

4

h



# RA 111291 D2661/ D2662

## SADDLES

### NCR11-935

Received @ Dart November 11<sup>th</sup>, 2011  
 Inspected @ Dart November 16<sup>th</sup>, 2011

#### Instructions for RA 111291 D2661/D2662 Saddles

- Qty X 34 saddles were returned
- **Following are to be SCRAPED**
  - D2662-2 B11028 QTY X 4, B9043 QTY X 2, B9042 QTY X 3
  - D2661-1 B64559 QTY X 5
  - D2661-2 B9913 QTY X 1, B10476 QTY X3, B10015 QTY X 1, B10016 QTY X 1
- Need a work order to scrap
- **Following are to be returned to STOCK**
  - D2662-2 B74482 QTY X 1, B74484 QTY X 1, B75118 QTY X 1
  - D2662-1 B73846 QTY X 2
  - D2661-1 B73839 QTY X 4
  - D2661-2 B74475 QTY X 4
- Need a separate work order for each model to return back in to stock

- D2662-2 B74483 was dropped by DS needs to be striped then assed by QC and if not damaged to be re powder coated and put back in to stock under a new BATCH #

Keep

✓ 76516 - D2661-1	4	73839
✓ 76517 - D2661-2	4	74475
✓ 76518 - D2662-1	2	73846
✓ 76519 - D2662-2	3	1-74482 1-74484 1-75118

Scrap

5	- 64559
6	1-9913 3-10476 1-10015 1-10016
7	
8	
9	4-11028 2-9043 3-3042

76521 ✓  
76523 ✓

